





GE★CHIL


Please read all of instructions before use

PARTS



Stand


-  Screws x4
-  Feet x4
-  Clamp & Thumb Screw



Heater

*sold separately

STAND ASSEMBLY






Heater should always be disconnected from power and cool before mounting or dismounting from Go-Coil™ Stand

HOW TO MOUNT HEATER



- 1** Thumb screw fully extended






- 2** Heater cord through clamp slot





- 3** Slide stand arm through clamp slot




- 4** Position heater on stand



For straight-arm D-Nail® heaters, position clamp along upper stand arm as shown




5 Tighten thumb screw against heater coupler or collar



Tighten thumb screw against black rubber sheath for best traction


IMPORTANT

Heater has 3 points of contact



Cross-Section View

CHECKLIST: Before plugging in heater



Misuse of product is extremely dangerous. If you have any difficulty or questions about mounting heater please email or message us.
email: info@d-nail.com instagram: [@d-nailusa](https://www.instagram.com/d-nailusa)



WARNINGS & PRECAUTIONS



Only use D-Nail® brand heaters in Go-Coil™ stand.

Check that heater is secure and clamp is tight before each use.

If heater becomes loose at any time, turn off heater and wait until cool to adjust and tighten.

Dont attempt to remove or adjust heater, stand, clamp or thumb screw while hot.

Turn off heater and allow to cool completely before removing.

Position heater in safe, secure place away from pets, children and other objects especially things that can burn or melt such as wood, cloth and plastic

Misuse of product is extremely dangerous.
If you have any difficulty or questions about mounting heater or fitting the correct heater please email or message us.



TM

D-NAIL.COM

info@d-nail.com



@dnailusa